

The following accessories are suitable for use with the Wildlife Camera (C10):

- Battery to Camera Extension Cable (A33)
- Mains to Battery Extension Cable (A35)
- Enjoy Birds More by PC (A36)
- Video to USB Converter (A37)
- PC Video Viewer (A38)
- Rechargeable High Capacity Battery Set (A40)
- Solar Panel (A41) (requires the Rechargeable High Capacity Battery Set)
- Wind Generator (A42) (requires the Rechargeable High Capacity Battery Set)
- Universal Camera Stand (A45)
- Bird Table Stand (A46)
- Network Server (A50)
- Scart Adaptor (A51)