

The following accessories are suitable for use with the Eco Dual Camera Kit):

- Battery to Camera Extension Cable (A33)
- Enjoy Birds More by PC (A36)
- Video to USB Converter (A37)
- PC Video Viewer (A38)
- Eco Box (A47)
- Network Server (A50)
- Scart Adaptor (A51)