

Product Content – Large Battery Box (A31)

1. Battery Box (black ABS), complete with
 - Holder for 4 x size “D” batteries
 - On/Off switch
 - Wall Bracket
 - 1.6 metre (approx) cable



2. Weather resistant connector cover



3. Suitable for use with: Eco Nest Box (B1), Bird Table Camera (C11), Eco Bird Feeder (F90) etc
4. User Guide

