

Enjoy Birds More

Mains to Battery
Extension Cable
(A35)



User Guide

Enjoy Birds More

Mains to Battery Extension Cable

Components

- 1 Cable
- 1 Polythene Tube
- 4 Cable Ties

Use

This is a 2 core low voltage extension cable designed to extend the distance between the Mains Power Supply Unit and the Battery Connector or Battery Box.

Fitting

1. Snap one end of this cable to the matching PP3 connector on the mains Power Supply Unit.
2. Snap the other end of the cable to the mating PP3 connector where you would have otherwise fitted the mains PSU, ie to the PP3 connector in the battery box (on the electronic or daylight sensing battery boxes this will either be attached very closely to the circuit board or marked with yellow sleeving) or the battery snap connector of the Eco Nest Box. If possible, ensure that the joint formed by these connectors is kept inside the box or otherwise in the dry.
3. If you wish to fit one of the cable joints outside, disconnect the connectors, fit the Polythene Tube over the cable and fit the connectors together again. Position the Tube so that it covers the joint and using 2 Cable Ties at each end, tighten it at each end over the two cables to make the joint weatherproof.
4. Plug in the PSU and check that the system works as it should, ie as it does when the PSU is connected directly to the Battery Box.

Specifications, Warranty etc

The specifications of the product described and the contents of this User Guide are subject to change without notice, as part of our continuous improvement process.

Whilst every care has been taken in the preparation of this document, we realise that it may still be possible to improve it. If you find any errors, omissions or points which are not clear, please let us know by email at user.guide@enjoybirdsmore.co.uk. We will endeavour to deal with the problem to your satisfaction, and learn from it for future versions.

The contents of this document may not be reproduced in whole or in part except for your personal use.

Enjoy Birds More Limited warrants all its products against defects in materials and manufacture for 6 months from the date of purchase. If a defect is discovered, Enjoy Birds More will repair or replace the product (at its option) free of charge, provided it is returned to the address in this User Guide at the customer's expense.

Enjoy Birds More Limited is not able to accept any responsibility for any loss, damage, or loss of data suffered by any customer or third party as a result of use, misuse or malfunction of the product or this User Guide. In particular, whilst the product has been extensively tested, we are unable to warrant that it is error free.

If you have any further technical or user questions relating to the product, please first check the Frequently Asked Questions section of our Web Site, www.enjoybirdsmore.co.uk. If that does not enable you to resolve your query, please email it to us on customer.service@enjoybirdsmore.co.uk.

From time to time, we provide customers with product updates. Please check the web site for details.

Care for the Environment

As you might expect, Enjoy Birds More cares deeply about the Environment. We have adopted an Environmental Policy designed to demonstrate our commitment to operating our business in harmony with the natural and man made environments. If you wish to see the full policy, it is available to read on our web site.

Our products are developed to be economical with natural resources, both in manufacture and use. We comply with the relevant laws and regulations, including those relating to the Restriction of Hazardous Substances (known as RoHS) and Waste Electronic and Electrical Equipment (WEEE).

The wood used in our products comes from responsibly managed forests, as part of our commitment to the FSC.

When you have finished using this product, please dispose of it responsibly. We would suggest using your local household recycling and waste treatment facility, particularly for the electronic parts of the product.

Certain of our products are marked with the following symbol:



This denotes that they require to be disposed of at end of their useful life by the local waste treatment facility. Please follow this instruction.

This User Guide is printed on recycled paper.

Enjoy Birds More Accessories

Our comprehensive range of accessories is designed to enable customers to make the best use of their products. Why not accessorise your equipment to extend its capabilities and make it do exactly what you want? The following accessories are suitable for our Nest Boxes and cameras:

Daylight Sensing Battery Box (A32)

Accessorise the Eco Nest Box to give it very long battery life, dusk/dawn switching, use of rechargeable batteries and also site the batteries away from the nest box in a convenient position for changing/switching. Wooden Battery Box with translucent lid matches Eco Nest Box.

Battery to Camera Extension Cable (A33)

Extend the distance from your battery or battery box to the Eco Nest Box or Wildlife Camera. Convenient battery changing and avoid disturbance when changing batteries.

Control / Battery Extension Cable (A34)

Extend the distance from your battery box to the Garden Nest Box.

Enjoy Birds More by PC (A36)

Our very own software package for users of camera nest boxes and wildlife cameras - view, take and archive your pictures, videos and timelapse sequences.

Video to USB Converter (A37)

This small converter allows you to feed pictures of your nest or wildlife straight into your computer. No need to install any hardware inside the computer.

PC Video Viewer (A38)

All the hardware and software you need to watch your nest and wildlife pictures on a PC or laptop.

Rechargeable High Capacity Battery Set (A40)

8 high capacity rechargeable batteries and mains charger. Last for longer between charges. (Use with Large Battery Box or Daylight Sensing Battery Box).

Solar Panel (A41)

Help save the planet by using renewable energy to operate your Nest Box or Camera. You may never need to change the batteries again (Use with Daylight Sensing Battery Box).

Wind Generator (A42)

Free energy to supplement solar or mains recharging for your Nest Box or Camera. Good looking and discreet generator (Use with Daylight Sensing Battery Box).

25 mm Hole Plate (A43)

Small plywood plate to fit on front of nest box, to reduce the size of the entrance hole, and limit the box to smallest bird species.

28 mm Hole Plate (A44)

Small plywood plate to fit on front of nest box, to reduce the size of the entrance hole, and limit the box to smaller bird species.

Eco Box (A47)

Another nest box to match your Eco Nest Box, but with no camera. Use it to increase your chances of attracting birds to nest. Swap the camera from one box to another in seconds if the birds choose the box without a camera.

Enjoy Birds More

Did you know we produce a Variety of Wireless Camera Nest Boxes, and Wildlife Cameras and Accessories? Some of our products:

Garden Nest Box (B2)

The ultimate Wireless Camera Nest Box, with a battery life up to 7 months, and bristling with innovations. Easy and Quick to set up. Remote Electronic Battery Box takes alkaline or rechargeable batteries, and is already equipped with charger to utilise solar or wind energy

Wildlife Camera (C10)

Watch birds and animals day or night with this high resolution colour camera, including infra red lights for night/dark viewing and sophisticated battery box. View on a TV , PC or laptop

Town Garden Nesting Package (P80)

Includes Garden Nest Box with all you need to watch by computer

Country Garden Nesting Package (P81)

Includes 2 Nest Boxes with all you need to watch by computer

Solar Nesting Package (P82)

The ultimate package for the environmentally conscious, with all you need to watch by computer and power by renewable energy

Wildlife Camera Package (P83)

Camera, stand and computer connection makes you ready to start viewing the wildlife immediately

Specialist Boxes:

Other specialised boxes and special requirements made to individual order.

To order, or for more details of all our products:

Visit us at www.enjoybirdsmore.co.uk,

Email us at mail@enjoybirdsmore.co.uk

Or telephone us at +44 (0) 1675 442544

Enjoy Birds More Limited
Eastcote House
Barston Lane
Eastcote
Solihull
West Midlands
B92 0HS UK

Telephone: +44 (0) 1675 442544

Fax: +44 (0) 1675 442421

Text (SMS): +44 (0) 1675 442544

Web site: www.enjoybirdsmore.co.uk

Email: mail@enjoybirdsmore.co.uk

This publication, our products and our designs are
© Copyright 2008 Enjoy Birds More Limited
and protected by Patent Pending 0424839.9

FSC
Trademark
© 1996
Forest
Stewardship
Council AC



Responsible
Forest
Management

SA-COC-001654-EK



All our products are tested
for compliance with the
relevant directives, and carry
the CE Mark



Finalist
2004